


Lighter

Turn key in steering lock to position "1" or "2".

Press in lighter; it will pop out automatically when hot.



Sliding Roof

Turn key in steering lock to position "2".

Press upper end (symbol) of rocker switch to open roof, press lower end to close.

If the electric drive fails, the sliding roof can also be moved by hand. Refer to "Emergency Operation of Sliding Roof" (page 77).